

Twine Knot CANDLE KIT

KIT DE BOUGIE

Noeud De Ficelle

BEGINNER LEVEL

1



First, we pour the two wax powders into the pot in a one-to-one ratio.

D'abord, nous versons les deux cires en poudre dans le récipient dans un ratio de un pour un.

2



Next pass the wick through the needle.

Ensuite, faites passer la mèche dans l'aiguille.

3



Pull it through the mold from the bottom and pull out the wick.

Tirez-la à travers le moule par le bas, puis faites sortir la mèche.

4



Take out the fixing stick and fix the candle wick.

Retirez le bâton de fixation et fixez la mèche de la bougie.




5



Then heat it up and stir it with a stirring stick to dissolve it.

Ensuite, faites chauffer et remuez avec un bâtonnet pour le faire fondre.


6



Next, add the dyeing block and stir to dissolve.

Ajoutez ensuite le bloc de colorant et remuez pour le dissoudre.

7



Pour the dissolved liquid into the mold.

Versez le liquide dissous dans le moule.

8



Then we demould it.

Ensuite, nous démoulons.

9



Then cut off the excess candle wick.

Puis coupez l'excédent de mèche.

10



and that completes the candle!

et voilà, la bougie est terminée!

Extra Tips for New Candle Makers

PREP WORK

- **Clean and prep your mold:** Even if it looks spotless, give it a quick wipe. Any lint or dust will show up in your candle.
- **You can use mold release spray (or light oil):** Makes it much easier to pop the candle out later.

WICK & POSITIONING

- **Center and secure the wick:** Tape, putty, or a wick bar will keep it from drifting. A crooked wick will result in an uneven burn.
- **Anchor the wick at the base:** A dab of hot glue or wax keeps it from floating when you pour.

POURING TECHNIQUE

- Don't pour too hot: If the wax is too hot, it can shrink dramatically or crack. Aim for the recommended pouring temperature for your wax type.
- Pour slowly and steadily: Rushing can trap air bubbles along the mold wall.
- Tap the mold gently: This helps bubbles rise and escape before the wax sets.

COOLING & UNMOLDING

- **Cool at room temperature:** Don't put the mold in the fridge or freezer—fast cooling leads to cracks.
- **Expect sinkholes:** Large molded candles often form dips as they cool. Save a little melted wax to top up and smooth out the surface.
- **Wait the right amount of time before unmolding:**
 - Small candles (tealight or votive size): 4–6 hours
 - Medium candles (pillar or small figural): 12–18 hours
 - Large or detailed molds: 24 hours is safest
- **Check readiness:** If the mold feels cool all the way through and the wax has pulled slightly from the edges, it's usually ready.

FINISHING TOUCHES

- **Trim the wick:** Leave about 1/4 inch.
- **Polish if needed:** Rubbing the candle lightly with a soft cloth can give it a nice sheen.

How to Melt Wax Safely at Home Using The Double Boiler Method

Melting wax the right way is key to great candle-making. The double boiler method is one of the safest and most effective techniques—perfect for beginners and pros alike.

DO NOT LEAVE CHILDREN ALONE WITH MELTED WAX OR THROUGH THE WAX MELTING PROCESS.

Here's how to do it:

- 1. Set up your base pot:** Fill a large saucepan with 1 to 2 inches of water and place it on the stove over low to medium heat.
- 2. Use a wax-safe container:** Place your wax into a smaller, heatproof container—think metal jug, glass pitcher, or another smaller pot. Just make sure it can handle both heat and water exposure.
- 3. Create the double boiler:** Once the water begins to heat up, carefully place your wax container inside the larger pot, letting it sit in the simmering water bath.
- 4. Maintain a gentle simmer:** As the wax melts, keep an eye on the water level. Add more water as needed to maintain a steady simmer—don't let the pot run dry!
- 5. Watch your temperature:** Use a candle-making thermometer to monitor the wax temperature. Aim for 160°F to 180°F (71°C to 82°C) for most wax types.
- 6. Remove and customize:** Once fully melted, take the wax off the heat. If you're adding fragrance or essential oils, now's the time to mix them in.

Recommended Wax Melting Temperature

160°F to 180°F
(71°C to 82°C)

- Always use a double boiler
- Monitor with a thermometer
- Work in a well-ventilated area



Température recommandé pour faire fondre la cire

160°F à 180°F
(71°C à 82°C)

- Utilisez toujours un bain-marie
- Surveillez la température avec un thermomètre
- Travaillez dans un endroit bien aéré

